



Notes:

1. Do not scale drawing.
2. Left hand shown.
3. When door is handed, push side of door must indicate whether door is inside or outside.
4. All dimensions are in inches (mm).

Installation Instructions:

- A. Attach angle bracket to frame.
- B. Attach door portion.
- C. Remove cap and pin from angle bracket.
- D. Install door on bottom pivot.
- E. Align top of door and angle bracket.
- F. Insert pin into both pivot pieces.
- G. Affix cap tightly.



340 x Angle Pivot 3 Top Pivot

RIXSON
ASSA ABLOY

www.rixson.com

TEMPLATE NUMBER

IS-340xAP3

DATE

07-09